


## Adjusting the Clutch Lever Freeplay

### I Upper Adjustment

Attempt adjustment with the upper clutch cable adjuster first.

1. Loosen the upper lock nut.
2. Turn the upper clutch cable adjuster until the freeplay is  $3/8$  to  $13/16$  in (10 to 20 mm).
3. Tighten the upper lock nut and check the freeplay again.



### I Lower Adjustment

If the upper clutch cable adjuster is threaded out near its limit, or the correct freeplay cannot be obtained, attempt adjustment with the lower clutch cable adjusting nut.