Items	Frequency	Whichever → comes first ↓		Initial Maint.	Regular maintenance interval				Refer to page
			km	150	1,000	2,000	3,000	4,000	
			mi	100	600	1,200	1,800	2,400	
		Note	Month	1	6	12	18	24	
*	Fuel line					I		I	–
*	Throttle operation					I		I	48
	Air cleaner	Note (1)			C	C	C	C	41
	Crankcase breather				I	I	I	I	43
	Spark plug				I	I	I	I	46
*	Valve clearance			I	I	I	I	I	–
	Engine oil			R	R	R	R	R	44
**	Engine oil strainer screen					C		C	–
**	Engine oil centrifugal filter					C		C	–
**	Engine idle speed			I	I	I	I	I	47
	Drive chain	Note (1)		I, L	every 500 km (300 mi) or every 3 months: I, L				49
	Drive chain slider				I	I	I	I	50
	Brake fluid	Note (2)			I	I	I	I	17
	Brake shoe/pad wear				I	I	I	I	55, 56
	Brake system			I	I	I	I	I	17, 55, 56
	Clutch system			I	I	I	I	I	19
	Side stand					I		I	59
*	Suspension					I		I	58, 59
*	Spark arrester			every 1,600 km (1,000 mi) or every 100 operating hours: C					49
*	Nuts, bolts, fasteners			I		I		I	–
**	Wheels/tyres			I	I	I	I	I	24, 53
**	Steering head bearings			I		I		I	–