

■ Removal

1. **CRF1100A/D**
Remove the bolts A and washers. using the hex wrench provided on the underside of the rear seat. ➡ P. 253
2. **CRF1100A4/D4**
Remove the bolt B, bolts A and washers. using the hex wrench provided on the underside of the rear seat. ➡ P. 253
3. Remove the collar.
4. Remove the skid plate by releasing its grommet from the prong.

■ Installation

1. Install the skid plate in the reverse order of removal.
2. Install the collar.
3. Install the washers onto the bolts A.
4. Tighten the bolts A.

Torque: 19 lbf·ft (26 N·m, 2.7 kgf·m).

5. **CRF1100A4/D4**

Install the washer onto the bolt B and tighten the bolt B.

Torque: 9 lbf·ft (12 N·m, 1.2 kgf·m).