

DESCRIPTION

PARTS LOCATION

- (1) Fuel tank cap
- (2) Throttle lever
- (3) Ignition/engine stop switch
- (4) Headlight switch
- (5) Oil filler cap
- (6) Foot peg
- (7) Brake pedal

