

<b>(Ref.No.) Description</b>	<b>Function</b>
(12) Multi-function display	The display includes the following functions; This display shows the initial display (page 24 ).
Low oil pressure indicator/High coolant temperature indicator/HESD indicator	Lights the low oil pressure indicator and/or high coolant temperature indicator to notify that there is an abnormality in engine oil pressure and/or coolant temperature when the warning indicator lights. See page 29 , 30 . Also, lights the HESD indicator to notify when there is an abnormality in the HESD (Honda Electronic Steering Damper) (page 31 ).
Speedometer	Shows riding speed (page 33 ).
Digital clock	Shows hour and minute (page 41 ).
Coolant temperature meter	Shows coolant temperature (page 26 ).