


3**Fuel Mixture
Enrichment Knob**

Pull out the fuel mixture enrichment knob (black) located on the carburetor.

4

Determine if the transmission is in gear by moving the motorcycle back and forth. If the motorcycle does not roll freely the transmission is in gear and must be placed in the neutral position before attempting to start the engine.

WARNING: Do not start the motorcycle while the transmission is in gear.