

Maintenance Schedule

ITEMS	FREQUENCY	WHICHEVER COMES FIRST		INITIAL MAINT.	REGULAR MAINT. INTERVAL		Refer to page
		⇒	km	150	1000	2000	
			mi	100	600	1200	
		NOTE	HOURS	20	100	200	
REAR FINAL GEAR CASE OIL				(RE:EVERY 2 YEARS)		107	
* BRAKE FLUID	NOTE 3					124	
* BRAKE SHOE WEAR	NOTE 1					135	
BRAKE SYSTEM						124	
* REVERSE LOCK SYSTEM						118	
SKID PLATES, ENGINE GUARD						144	
* CLUTCH SYSTEM						117	
* SUSPENSION						—	
* SPARK ARRESTER				C	C	145	
* NUTS, BOLTS, FASTENERS						—	
** WHEELS/TYRES						—	
** STEERING SHAFT HOLDER BEARINGS						—	
** STEERING SYSTEM						—	

* Should be serviced by your Honda dealer, unless you have the proper tools and service data and are mechanically qualified. Refer to the official Honda Shop Manual.

** In the interest of safety, we recommend these items be serviced only by your Honda dealer.