

5. Tyres—check condition and pressure (pages 42 – 47 ).
6. Drive chain—check condition and slack (page 108 ). Adjust and lubricate if necessary.
7. Throttle—check for smooth opening and full closing in all steering positions.
8. Lights and horn—check that headlight, brake/tail light, turn signals, indicators and horn function properly.
9. Engine stop switch—check for proper function (page 54 ).
10. Side stand ignition cut-off system—check for proper function (page 115 ).