

## STARTING PROCEDURE

Follow the procedure below for all temperature starting:

1. Pull the choke lever (1) all the way down.
2. Start the engine, leaving the throttle closed.

**NOTE:** Do not open the throttle when starting the engine with the choke lever down. This will lean the mixture, resulting in hard starting.

**CAUTION:** The red oil pressure warning light should go off a few seconds after the engine starts. If the light stays on, stop the engine immediately and check engine oil level. Do not operate the engine with insufficient oil pressure.

3. Immediately after the engine starts, operate the choke lever (1) to keep the engine speed at 1,500—2,500 rpm.
4. About a half minute after the engine starts, push the choke lever (1) all the way up.

