


## Stoplight Switch Adjustment

Check the operation of the stoplight switch (1) at the right side behind the engine from time to time.

Adjustment is done by turning the adjusting nut (2). Turn the nut in the direction (B) if the switch operates too late and in direction (A) if the switch operates too soon.



## Tool Kit

The tool kit is behind to left side cover. Tool kit cover can be removed with a key (1). Listed below are the items included in the tool kit (2).

- 8 × 12 mm spanner
- 10 × 12 mm spanner
- 14 × 17 mm spanner
- Pliers
- No. 2 minus screw
- No. 2 plus screwdriver
- No. 3 plus screwdriver
- Screwdriver grip
- 5 mm hex wrench
- 24 mm eye wrench
- Spark plug wrench
- Lever
- 120 mm handle eye wrench
- Tool bag

