
## **Starting the Engine** (Continued)

3 Turn the ignition switch to the (On) position.



## 4 Using the start button

With the throttle closed, press the start button. Release the start button as soon as the engine starts.

