
## **Storage Equipment**



## **Seat Open**

- 1 Turn the handlebar pointed straight ahead.
- 2 Insert the ignition key into the seat lock and turn it clockwise to unlock.
- 3 Open the seat.

## **Seat Close**

Close and push down on the rear of the seat until locks. Make sure that the seat is locked securely to pull it up lightly.

Take care not to lock your key in the compartment under the seat.