


## Hook


The hook is provided below the handlebar.

- ▶ Do not attach large luggage to the hook that would hang out from the scooter and/or interfere with the movement of your feet.



## Glove Boxes

The glove boxes are provided below the handlebar.



Glove boxes

The maximum allowable load on the hook and in the glove boxes shall be no more than **1.5 kg (3.3 lb)**.