

Engine

Number.....	133, 133
Oil.....	64, 84
Oil Filter.....	86
Overheats.....	107
Starting.....	45
Stop Switch.....	42, 126
Stopping.....	126
Will Not Start.....	106

Environment	132
--------------------------	-----

Equipment

Document Bag.....	50
Helmet Holder.....	49
Owner's Manual.....	126
Tool.....	50

F

Flooded Engine	45
-----------------------------	----

Front Seat	76
-------------------------	----

Front Turn Signal Light	120
--------------------------------------	-----

Fuel

Average Fuel Mileage Meter.....	19, 25
Consumption Meter.....	19, 26
Containing Alcohol.....	147

Current Fuel Mileage Meter.....	19, 25
---------------------------------	--------

Gauge.....	19, 110
------------	---------

Recommended.....	48, 147
------------------	---------

Remaining.....	19
----------------	----

Tank Capacity.....	48, 147
--------------------	---------

Fuses	63, 121
--------------------	---------

G

Gasohol	140
----------------------	-----

Gasoline	48
-----------------------	----

H

Headlight	119
------------------------	-----

Headlight Aim	103
----------------------------	-----

Headlight Dimmer Switch	42
--------------------------------------	----

Helmet Holder	49
----------------------------	----

High Beam Indicator	39
----------------------------------	----

Honda Contacts	144
-----------------------------	-----

Horn Button	42
--------------------------	----

I**Ignition Cut-off System**

Banking Sensor.....	126
---------------------	-----

Side Stand.....	93
-----------------	----