

# Parts Location

Rear brake fluid reservoir ➔ P.72

Battery ➔ P.59

Document bag ➔ P.38

Fuse box ➔ P.105

Main fuse ➔ P.106

Engine oil fill cap ➔ P.65

Front brake fluid reservoir  
➔ P.72

Front brake lever

Throttle grip ➔ P.83

Engine oil filter ➔ P.67

Engine oil level inspection  
window ➔ P.65

Rear brake pedal

