

# Maintenance

Please read “Importance of Maintenance” and “Maintenance Fundamentals” carefully before attempting any maintenance. Refer to “Specifications” for service data.

An optional larger tool kit may be available. Check with your Honda dealer’s parts department.

<b>Importance of Maintenance</b> .....	P. 40	<b>Coolant</b> .....	P. 70
<b>Maintenance Schedule</b> .....	P. 42	<b>Brakes</b> .....	P. 72
<b>Maintenance Fundamentals</b> .....	P. 45	<b>Side Stand</b> .....	P. 75
<b>Removing &amp; Installing Body Components</b> ...	P. 59	<b>Drive Chain</b> .....	P. 76
Battery .....	P. 59	<b>Clutch</b> .....	P. 80
Clip .....	P. 60	<b>Throttle</b> .....	P. 83
Headlight Assembly .....	P. 61	<b>Crankcase Breather</b> .....	P. 84
Rear Seat .....	P. 62	<b>Other Adjustments</b> .....	P. 85
Front Seat .....	P. 63	Headlight Aim .....	P. 85
Side Cover .....	P. 64	Rear Suspension .....	P. 86
<b>Engine Oil</b> .....	P. 65		
<b>Air Cleaner</b> .....	P. 69		