


Position Light Bulb



1. Remove the bulb lid. [▶ P. 60](#)
2. Pull off the socket without turning.
3. Pull out the bulb without turning.
4. Install a new bulb and reinstall the parts in the reverse order of removal.