The average fuel mileage and fuel consumption will be based on tripmeter A.

- Current fuel mileage:
 - Current instant fuel mileage. If your speed is less than 5 mph (7 km/h), " --- " is displayed.
 - When " --- " is displayed at speeds above 5 mph (7 km/h), go to your dealer for service.
- Average fuel mileage:
 - Average fuel mileage since tripmeter A was reset. When " --- " is displayed, go to your dealer for service.
- Fuel consumption:
 - Total fuel consumption since tripmeter A was reset. When " ---- " is displayed, go to your dealer for service.
 - ► To reset the average fuel mileage and fuel consumption: →P.22