

## Instruments (Continued)

### Setting Mode A

If the buttons are not pressed for about 30 seconds, the control is automatically switched from the setting mode to the ordinary display.

If the buttons are not pressed for about 30 seconds, items in the process of being set will be discarded and only items where settings have been finalised will be applied. Only if the ignition switch is turned to the **O** (Off) position, items in the process of being set and those that are finalised will be applied.

### 1 Clock setting:

- 1 Turn the ignition switch to the **I** (On) position.
- 2 Select the odometer, tripmeter A or tripmeter B. **▶P.18**
- 3 Press and hold **SEL** and **SET** buttons until the hour digits start flashing.



- 4 Press **SEL** button until the desired hour is displayed.

▶ Press and hold the **SEL** button to advance the hour fast.

