

# Maintenance

Please read “Importance of Maintenance” and “Maintenance Fundamentals” carefully before attempting any maintenance. Refer to “Specifications” for service data.

An optional tool kit may be available. Check with your Honda dealer’s parts department.

<b>Importance of Maintenance</b> .....	P. 52	<b>Side Stand</b> .....	P. 85
<b>Maintenance Schedule</b> .....	P. 54	<b>Drive Chain</b> .....	P. 86
<b>Maintenance Fundamentals</b> .....	P. 57	<b>Clutch</b> .....	P. 90
<b>Removing &amp; Installing Body Components</b> ...	P. 70	<b>Throttle</b> .....	P. 93
Front Seat .....	P. 70	<b>Other Adjustments</b> .....	P. 94
Rear Seat .....	P. 71	Brake Lever .....	P. 94
Single Seat Cowl.....	P. 72	Front Suspension .....	P. 95
Lower Fairing .....	P. 73	Rear Suspension .....	P. 100
Battery .....	P. 74	Headlight Aim .....	P. 104
<b>Engine Oil</b> .....	P. 76		
<b>Coolant</b> .....	P. 80		
<b>Brakes</b> .....	P. 82		