

Stopping.....	128
Environment.....	136

F

Flooded Engine.....	46
Front Brake Lever Adjustment.....	94
Front Seat.....	70
Front Suspension.....	95

Fuel

Consumption Meter.....	24
Low Fuel Indicator.....	41, 43
Mileage Meter.....	24
Oxygenated.....	144
Recommended.....	48
Remaining.....	41, 43
Tank Capacity.....	48

Fuses.....	62, 123
------------	---------

G

Gasohol.....	144
Gasoline.....	48

H

Headlight Aim.....	104
Headlight Dimmer Switch.....	44
Helmet Holder.....	50
HESD (Honda Electronic Steering Damper).....	129
HESD (Honda Electronic Steering Damper) Indicator.....	41
High Beam Indicator.....	40
High Coolant Temperature Indicator.....	40, 107
Honda Contacts.....	148
Horn Button.....	44

I

Ignition Cut-off System

Banking Sensor.....	129
Side Stand.....	85
Ignition Key.....	127
Ignition Switch.....	44, 45, 128
Indicators.....	40
Information Record.....	155
Instruments.....	22