

Instruments (Continued)



Tripmeter [A/B] & Fuel mileage meter & Fuel consumption meter

[SEL] button selects the tripmeter A, tripmeter B, current fuel mileage, average fuel mileage and fuel consumption.

► To reset the tripmeter: (P26)

