



Instruments *(Continued)*



 Press the **MODE** button

 Press and hold the **MODE** button and **SEL ▲** (up) or **SEL ▼** (down) button

 Press the **SEL ▲** (up) button

 Press the **SEL ▼** (down) button

To end the setting

Select the "EXIT" menu on the main menu screen, or press and hold the **MODE** button and **SEL ▲** (up) or **SEL ▼** (down) button. Also, the setting mode is ended when your motorcycle speed reaches approximately 1 mph (1 km/h).

▶ Press and hold the **MODE** button and **SEL ▲** (up) or **SEL ▼** (down) button to return to the ordinary display.

Note that doing so cancels the settings left incomplete.