

FUNCTION

To Set the FUNCTION Menu

- 1 Select the "FUNCTION" menu on the main menu screen. **➡P.43**
- 2 Select a menu by pressing the **SEL ▲** (up) or **SEL ▼** (down) button and press the **MODE** button.

To end the setting

Select the **◀** (return) on the menu screen. The display returns to the "FUNCTION" menu on the main menu screen.

-  Press the **MODE** button
-  Press the **SEL ▲** (up) button
-  Press the **SEL ▼** (down) button

"FUNCTION" is selected

