









Instruments *(Continued)*


INFO 3

You can select the “CBR LOGO”, “REV IND NE”, “GRIP ANGLE”, “VOLTAGE”, “DATE”, “USER LETTER” or blank display for INFO 3.

- 1 Select the “INFO 3” using the **SEL**  (up) or **SEL**  (down) button, and press the **MODE** button.
 - ▶ Press and hold the **SEL**  (up) or **SEL**  (down) button to move the menu quickly.

12:34		SETTING	0 mph
FUNCTION	BACKGROUND		
LAP TIME	USER LETTER		INFO 2
DISPLAY FAVORITE			INFO 3
GENERAL			
SERVICE	DISPLAY MODE		INFO 1

- 2 Select the “CBR LOGO”, “REV IND NE”, “GRIP ANGLE”, “VOLTAGE”, “DATE”, “USER LETTER” or blank display using the **SEL**  (up) or **SEL**  (down) button.
 - ▶ Press and hold the **SEL**  (up) or **SEL**  (down) button to move the menu quickly.

12:34		SETTING	0 mph
FUNCTION	BACKGROUND		USER LETTER
LAP TIME	USER LETTER		
DISPLAY FAVORITE			CBR LOGO
GENERAL			REV IND NE
SERVICE	DISPLAY MODE		GRIP ANGLE

- 3 Press the **MODE** button. The “INFO 3” setting is set, and then the display returns to the upper level hierarchy.