## **Other Warning Indications**

## **Fuel Gauge Failure Indication**

If the fuel system has an error, all segments will blink or go off as shown in the illustration.

If this occurs, see your dealer as soon as possible.



## **Coolant temperature Gauge Failure Indication**

If the cooling system has an error, all segments will blink or go off as shown in the illustration.

If this occurs, see your dealer as soon as possible.

