


- Odometer:
Total distance ridden.
 - Tripmeter:
Distance ridden since tripmeter was reset.
- To reset the tripmeter:**  **P.18**
- The average fuel mileage and fuel consumption will be based on tripmeter A.
- Current fuel mileage:
Current instant fuel mileage. If your speed is less than 5 km/h (3 mph), “--.-” is displayed.
 - ▶ When “---.-” is displayed at speeds above 5 km/h (3 mph), go to your dealer for service.
 - Average fuel mileage:
Average fuel mileage since tripmeter A was reset.
 - ▶ When “--.-” is displayed, go to your dealer for service.
 - Fuel consumption:
Total fuel consumption since tripmeter A was reset.
Above 300 L : “300.0” is displayed.
 - ▶ When “---.-” is displayed, go to your dealer for service.

To reset the average fuel mileage and fuel consumption:  **P.18**