

Setting Mode B

1 Setting of REV indicators:

You can change the setting of the REV indicators.

You can set each value of the blinking RPM with **Sport+**, **Sport** and **Comfort** mode. The order of setting is **Sport+**, **Sport**, and **Comfort** mode.

- 1 To change the setting mode B, turn the ignition switch to the ON position while pressing **SEL** button until the display check is finished. The blinking of bar segment in the tachometer shows the currently applied blinking RPM, and the numerical tachometer display shows it. At the same time, all of the REV indicators and **Sport+** mode blink.

