

<b>F</b>	
Flooded Engine .....	34
Front Seat .....	62
<b>Fuel</b>	
Gauge .....	19
Recommended .....	36
Remaining .....	19, 20
Tank Capacity.....	36
Fuses.....	50, 104
<b>G</b>	
Gasohol .....	121
Gasoline .....	36, 121
<b>H</b>	
Hazard Switch.....	32
Headlight Aim .....	84
Headlight Dimmer Switch.....	32
Helmet Holder .....	37
High Beam Indicator .....	31
High Coolant Temperature Indicator.....	30
Honda Contacts .....	124
Horn Button.....	32
<b>I</b>	
Ignition Cut-off System	
Banking Sensor .....	108
Side Stand .....	74
Ignition Key.....	107
Ignition Switch.....	33
Indicators.....	30
Information Record .....	130
Instruments .....	18
<b>L</b>	
Labels.....	7
Load Limits.....	15
Loading Guidelines.....	15
Low Oil Pressure Indicator .....	30, 89
<b>M</b>	
Maintenance	
Fundamentals .....	45
Importance .....	40
Safety .....	41
Schedule.....	42
Maximum Weight Limit .....	15