

<b>M</b>	
<b>Maintenance</b>	
Fundamentals .....	46
Importance .....	41
Safety .....	42
Schedule.....	43
<b>Maximum Weight Limit .....</b>	<b>15</b>
<b>Modifications.....</b>	<b>14</b>
<b>N</b>	
<b>Neutral Indicator .....</b>	<b>31</b>
<b>O</b>	
<b>Odometer.....</b>	<b>20, 105</b>
<b>Oil</b>	
Engine .....	52, 62
<b>Overheating .....</b>	<b>85</b>
<b>Oxygenated Fuels.....</b>	<b>119</b>
<b>P</b>	
<b>Parking .....</b>	<b>12</b>
<b>Parts Location.....</b>	<b>16</b>
<b>Passing Light Control Switch.....</b>	<b>32</b>
<b>PGM-FI (Programmed Fuel Injection)</b>	
<b>Malfunction Indicator Lamp (MIL).....</b>	<b>30, 86</b>
<b>Protective Apparel.....</b>	<b>9</b>
<b>R</b>	
<b>Rear Suspension.....</b>	<b>82</b>
<b>Recommended</b>	
Coolant.....	55
Engine Oil .....	52, 127
Fuel.....	37
<b>Refueling.....</b>	<b>37</b>
<b>Removal</b>	
Battery.....	60
Seat.....	61
<b>Repair Kit .....</b>	<b>89</b>
<b>Reporting Safety Defects.....</b>	<b>125</b>
<b>Riding Precautions .....</b>	<b>10</b>
<b>S</b>	
<b>Safety Guidelines .....</b>	<b>3</b>
<b>Safety Labels .....</b>	<b>7</b>
<b>Safety Precautions.....</b>	<b>9</b>
<b>Seat .....</b>	<b>61</b>
<b>Shifting Gears .....</b>	<b>36</b>