


Instruments (Continued)

- 3 Touch the center on each of the four crosses.

► The screen flashes green when

calibration is complete.

If calibration fails, the screen flashes red. Try step **3** again.




- 4 Return to the riding information, previous screen or Home screen. **➡P.38**

You can also perform the above settings by using the touch screen.

Service Mode

CRF1100A4/D4

The cornering light can be turned on when the vehicle is stopped for inspection.



- 1 Start the engine. **➡P.200**
- 2 Stop the vehicle.
- 3 Select [Service Mode], and then press the **ENT** switch.