

## Audio System (Continued)

### To Adjust the Volume

You can adjust the volume settings for the headsets.

The system has the following unique volume levels.


Adjust the volume while in the individual modes.

- [Music]
- [Phone]
- [System]
- [Ringtone]
- [Voice]
- [CarPlay]
- [Microphone]

Each volume can also be set from the menu.



When you push forward or pull backward the  function lever, the volume control level appears on the pop-up information.



 Push forward the  function lever

 Pull backward the  function lever