

Audio System (Continued)

When you push **VOL** lever up or down, the volume control level appears on the information bar.



To increase the volume: push **VOL** lever up.

▶ To increase the volume rapidly, push up and hold **VOL** lever.

To decrease the volume: push **VOL** lever down.


▶ To decrease the volume rapidly, push down and hold **VOL** lever.

VOLUME level range: Level 0 to 30



To mute the volume: Press and hold **SOURCE** switch.

▶ A diagonal line appears in the audio output status icon on the screen.



To resume the volume: Operate **VOL** lever while volume is muted.