











General Setting

Configures system settings.

Rotate , or press \blacktriangle / \blacktriangledown on the 4-way key switch to select a setting menu. Press  or [ENT] switch to set your selection.





The general settings contain the following:

- [Beep]  P.77
- [Language]  P.77
- [TTS Language]  P.78
- [Clock]  P.78
- [System Information]  P.80
- [Apple CarPlay/iPod]  P.80
- [System Reset]  P.80
- [Restore Apple CarPlay Settings]  P.81

Beep

Enables/disables the beep sound when operating keys.








- 1 Select [Beep], and then press  or [ENT] switch to select (enable) or deselect (disable) the function.
 \blacktriangleright You cannot deactivate the beep sound for error or caution messages.
- 2 Return to the previous screen or the Home screen.  P.24

Default: On (selected)

Language

Changes the system language.



- 1 Select [Language], and then press  or [ENT] switch.
- 2 Rotate  or press \blacktriangle / \blacktriangledown on the 4-way key switch to select the display language that you want to use on the screen, and then press  or [ENT] switch to set your selection.
- 3 Return to the previous screen or the Home screen.  P.24

Available languages: [US English]/ [CA Francois]/[NA Espanol]

Default: [US English]