

Audio System *(Continued)*

Connecting your iPhone/iPod/USB device

You can connect your iPhone/iPod/USB device using a certified cable to the USB connector or connect a USB flash drive, etc. to the USB connector directly.

Make sure to use the factory USB cable that came with your device.

- Some USB flash drives maybe unsupported or incompatible and will cause abnormal audio function, such as skipping or playing delays.
- Do not use hard disks, card readers, and memory readers which may damage the device and data. If you accidentally connect the one of them, turn the ignition switch OFF and remove it.

Compatible Devices

iPhone, iPod and other devices compatible with your audio system are:

USB flash drive	Standard File systems	USB 2.0/3.0 FAT32 (recommendation), FAT16, HFS+
	Storage capacities	From 256 MB to 64 GB
	Maximum hierarchies	8 hierarchies
	Maximum folders	512 folders
	Maximum files	65,524 files (same limitation in one folder)
	Maximum file/ folder name size	255 characters
	Maximum file size	2 GB (in single file)
	iPhone® 5 or later	iOS 10 or later
iPod touch® (5th generation or later)	iOS 9 or later	
iPod nano® (7th generation or later)		
iPad®/iPad Air®/iPad Mini® (all model)	Not supported	
iPod classic®/iPod shuffle® (all model)	Not supported	
Hard disk drive	Not supported	
Card reader/Memory reader	Not supported	
CD/DVD/FD drive	Not supported	
USB hub	Not supported	

The audio system may not be compatible with the latest model and the latest OS version.