


Clock (12-hour display)To set the clock:  P.27**Tachometer****NOTICE**

Do not operate the engine in the tachometer red zone. Excessive engine speed can adversely affect engine life.

Tachometer red zone

(excessive engine rpm range)

Speedometer**Fuel gauge**

Remaining fuel when only 1st (E) segment starts flashing:
approximately 1.06 US gal (4.0 liters)



If the fuel gauge indicators flash in an irregular (abnormal) pattern or turns off:  P.108