

Loading Guidelines.....	16
Low fuel indicator.....	27
Low Oil Pressure Indicator	26, 92

M

Maintenance

Fundamentals	44
Importance	39
Safety	40
Schedule.....	41

Maximum Weight Limit	16
-----------------------------------	-----------

Modifications.....	15
---------------------------	-----------

N

Neutral Indicator	27
--------------------------------	-----------

O

Odometer.....	24, 112
----------------------	----------------

Oil

Engine.....	51, 68
Final Drive	52, 75

Overheating	91
--------------------------	-----------

Oxygenated Fuels.....	126
------------------------------	------------

P

Parking	13
----------------------	-----------

Parts Location	20
-----------------------------	-----------

PGM-FI (Programmed Fuel Injection)

Malfunction Indicator Lamp (MIL).....	27, 92
--	---------------

Protective Apparel.....	9
--------------------------------	----------

R

Rear Suspension.....	87
-----------------------------	-----------

Recommended

Coolant.....	52
Engine Oil	51
Final Drive Oil.....	52
Fuel	34

Refueling.....	34
-----------------------	-----------

Removal

Battery.....	58
Clip.....	59
Seat.....	60
Side Cover	63

Repair Kit	94
-------------------------	-----------

Reporting Safety Defects.....	131
--------------------------------------	------------

Riding Precautions	11
---------------------------------	-----------