

Service item	F.R.T.	Ref. Nº	Part No.	Description	Quantity		Exch.	Serial No.
					XR200R	NX200		
Cable Comp., Throttle0.5 (One or All) • Switch Assy., Winker Cable Comp., Choke0.3 • Switch Assy., Starter Kill • Pipe, Throttle Grip Cable Comp., Clutch0.2 • Grip, R. Handle • Housing, Throttle Under • Bracket, L. Handle Lever Switch Assy., Clutch0.1 • Grip, L. Handle • Lever, L. Steering Handle • Guard, L. Knuckle		1	17910-KBB-900	Cable, Comp. A Throttle	1	—		
		2	17913-KB7-000	Cover, Throttle.....	1	—		
		3	17920-KBB-900	Cable Comp. B. Throttle	1	—		
		4	17950-KBB-900	Cable Comp., Choke	1	—		
		5	22870-KBB-900	Cable Comp., Clutch	1	—		
		6	35130-KBB-900	Switch Assy., Starter Kill	1	—		
		7	35200-KBB-900	Switch Assy., Winker.....	1	—		
		8	35330-MK5-003	Switch Assy., Clutch	1	—		
		9	53141-429-000	Pipe, Throttle Grip	1	—		
		10	53165-MK5-010	Grip, R. Handle	1	—		
		11	53166-MK5-010	Grip, L. Handle.....	1	—		
		12	53167-KAS-900	Housing, Throttle Upper.....	1	—		
		13	53168-KAS-900	Housing, Throttle Under.....	1	—		
		14	53169-KB7-000	Slider, Throttle Cable	1	—		
		15	53172-KS5-700	Bracket, L. Handle Lever	1	—		
		16	53174-KE1-000	Holder, L. Lever Bracket	1	—		
		17	53177-KW8-900	Cover, L. Handle Lever	1	—		
		18	53178-MG7-003	Lever, L. Steering Handle	1	—		
		19	53181-KN5-670	Plate, Guard Setting.....	1	—		
Artículo de Servicio	THLL	Nº de Ref.	Nº de Pieza	Descripción	Nº rdo.		Nota	Nº de série
					XR200R	NX200		
Cable Comp., Acelerador0.5 (Una o Todas) • Interruptor, Luz Intermitente Cable, Comp., Estrangulador0.3 • Ens. Interruptor, Parada Motor • Tubo Empuñadura Der. Cable Comp. Embrague.....0.2 • Empuñadura Der. • Caja, Acelerador, Inferior • Soporte, Palanca, Izq. Interruptor Embrague0.1 • Empuñadura Izq. • Palanca Comp., Embrague • Protector Palanca Embrague		1	17910-KBB-900	Cable Comp. A, Acelerador.....	1	—		
		2	17913-KB7-000	Caja, Cable Acelerador	1	—		
		3	17920-KBB-900	Comp. Cable B, Acelerador.....	1	—		
		4	17950-KBB-900	Cable Comp. Estrangulador	1	—		
		5	22870-KBB-900	Cable Comp. Embrague	1	—		
		6	35130-KBB-900	Ens. Interruptor, Parada Motor.....	1	—		
		7	35200-KBB-900	Interruptor, Luz Intermitente.....	1	—		
		8	35330-MK5-003	Interruptor, Embrague.....	1	—		
		9	53141-429-000	Tubo, Empuñadura, Izq.	1	—		
		10	53165-MK5-010	Empuñadura, Der.....	1	—		
		11	53166-MK5-010	Empuñadura, Izq.	1	—		
		12	53167-KAS-900	Caja, Acelerador, Superior	1	—		
		13	53168-KAS-900	Caja, Acelerador, Inferior.....	1	—		
		14	53169-KB7-000	Deslizador, Cable Acelerador.....	1	—		
		15	53172-KS5-700	Soporte, Palanca Izq.....	1	—		
		16	53174-KE1-000	Fijador, Izq. Soporte Palanca.....	1	—		
		17	53177-KW8-900	Cubierta, Palanca Izq.	1	—		
		18	53178-MG7-003	Palanca, Embrague	1	—		
		19	53181-KN5-670	Placa, Fijación, Protector	1	—		