


F-10

STEERING STEM/COMBINATION SWITCH(E/ED/F)

F14



Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
1	6141A2	RECEIVER UNIT, IMMOBILIZER ...	1.9
2	615145	SWITCH, COMBINATION & LOCK ...	2.2
3	615145	SWITCH, COMBINATION & LOCK ...	2.2
4	6151C2	BASE, CONTACT ...	1.9
7	6151E8	SWITCH, SEAT AND BOX ...	1.7
15	510100	STEM OR SHAFT ASSY., STEERING	2.1
16	5101B2	THREAD, STEERING HEAD TOP ...	1.9
21	5101B6	BEARING, HEAD PIPE :UPPER ...	2.1
22	5101B7	BEARING, HEAD PIPE :LOWER ...	2.3
	5101C7	BEARING, HEAD PIPE :BOTH ...	2.3

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			NSS 300 D	NSS 300A D	
1	30430-K04-305	RECEIVER UNIT SET	1	1	----- E,ED,F
2	35014-K04-305	KEY SET(IMMOBI)	1	1	----- E,ED,F
3	35100-K04-931	SWITCH ASSY., COMBINATION & LOCK	1	1	----- E,ED,F
4	35101-K04-931	BASE COMP., CONTACT	1	1	----- E,ED,F
5	35113-MFJ-D01	EMBLEM, KEY	4	4	----- E,ED,F
			(2)	(2)	----- E,ED,F
6	35121-K04-305	KEY, BLANK(IMMOBI)	(1)	(1)	----- E,ED,F
7	35190-K27-V01	SWITCH ASSY., FUEL LID & SEAT OPENER	1	1	----- E,ED,F
8	35191-K27-V01	COVER, CABLE	2	2	----- E,ED,F
9	35195-K04-931	SWITCH ASSY., L. LID OPENER	1	1	----- E,ED,F
10	50211-K04-930	STAY COMP., INNER	1	1	----- E,ED,F
11	50306-GN5-900	NUT, STEERING STEM LOCK	1	1	----- E,ED,F
12	53113-MCT-010	SEAL, HANDLE POST	1	1	----- E,ED,F
13	53213-MB4-771	DUST SEAL, STEERING UPPER (ARAI)	1	1	----- E,ED,F
14	53214-MR7-003	DUST SEAL, STEERING HEAD(ARAI)	1	1	----- E,ED,F
15	53219-K04-930	STEM SUB ASSY., STEERING	1	1	----- E,ED,F
16	53220-KYJ-900	THREAD COMP., STEERING HEAD TOP	1	1	----- E,ED,F
17	90101-MT4-000	SCREW, SCREEN SETTING	4	4	----- E,ED,F
18	90102-KVZ-630	BOLT, FLANGE, 10X45	4	4	----- E,ED,F
19	90107-MBG-000	BOLT, ONE-WAY, 8MM	2	2	----- E,ED,F
20	90506-MCT-000	WASHER, LOCK NUT	1	1	----- E,ED,F