
Clutch lever (P90)
Front suspension rebound damping/compression damping adjuster (P95) (P96)
Fuel fill cap (P48)
Front seat (P70)
Rear seat (P71)
Rear suspension compression damping adjuster (P101)
Rear suspension rebound damping adjuster (P101)
Drive chain (P86)
Rear suspension spring preload adjuster (P100)
Shift lever (P47)
Side stand (P85)
Front suspension spring preload adjuster (P95)

continued