
Clutch lever (P90)
Front suspension spring preload/rebound damping adjuster (P97) (P98)
Fuel fill cap (P48)
Front seat (P70)
Single seat cowl (P72)
Rear suspension compression damping adjuster (P103)
Rear suspension rebound damping adjuster (P103)
Drive chain (P86)
Rear suspension spring preload adjuster (P102)
Shift lever (P47)
Side stand (P85)
Front suspension spring preload/compression damping adjuster (P97) (P99)