

# Riding

## Starting the Scooter

!a Push the scooter forward off the center stand.

- ▶ Apply the rear brake lock. ( P29)
- ▶ Keep throttle closed.

Make sure the side stand and center stand are up.

!b Get on the scooter.

- ▶ Mount the scooter from the left side, keeping at least one foot on the ground.

- !c Release the brake lock.  
Squeeze and hold the rear brake lever (a ).  
Press the brake lock knob down while pushing in the center button (b ).
- ▶ To prevent unexpected movement, squeeze both brake levers.

